

## Kit Cutter Electric with accessories



### **E.C. CUTTER KIT** includes :

- electric scissor
- all-purpose blade, used for straight, quick cutting
- shoe blade, used for patterns and fabric
- rechargeable D.C. battery
- A.C. adapter
- charger
- power cord

These scissors cut fabric, patterns, leather and paper quickly ! The new, lightweight, ergonomical design helps to reduce wrist and hand strain. The handy rechargeable battery makes the scissors extremely portable and easy-to-use !

**LEGAL NOTES:** SICOMIN reserves the right to change the properties of its products. All technical data stated in this Product Data Sheet are based on laboratory tests. Actual measured data and tolerance may vary due to circumstances beyond our control. No warranties of any kind are made except that the materials supplied are of standard quality. All risk and liabilities arising from handling, storage and use of products, as well as compliance with applicable legal restrictions, rests with the user.

**MENTIONS LÉGALES :** SICOMIN se réserve le droit de modifier les propriétés du produit. Toutes les caractéristiques spécifiées dans cette Fiche technique sont basées sur des tests de laboratoire. Les mesures et leurs tolérances effectives peuvent varier pour différentes raisons. SICOMIN se réserve le droit Aucune garantie de quelque nature que ce soit, sauf que les matériaux fournis sont de qualité standard. Tous les risques et responsabilités découlant de la manutention, le stockage et l'utilisation des produits, ainsi que le respect des restrictions légales applicables, incombe à l'utilisateur.